

Willys Truck, Wagon & Delivery Hood Bumper

To Install:

- Measure and centerpunch hole location as shown below.
- Drill $9/64$ " holes and tap for the supplied 8-32 stainless steel screws

