

'46 to '51 Willys Truck, Wagon & Delivery Replacement Door Buttons

To Install:

- Remove the worn or broken stock Willys door button.
- Align the tabs at the rear of the Crossley's Garage button with the slots in the door mechanism.
- Insert one tab and push firmly to that side to snap in the second tab.
- For proper retention, use a soldering iron to gently heat swage the tabs as shown below. Alternatively, an epoxy adhesive could be used but...

Fun Fact: the original Willys heat swage was a typical assembly method of the time and has held strong for over 70 years!

